



Installation Instructions



Timber Floor Example

This option involves cutting the floor boards where the Marmox shower tray will drop into.


Centre or Offset Shower Tray



Polyurethane adhesive

NOTE: The shower tray must be fully supported.


Channel Shower Tray



Concrete Floor Example


This option is perfect for applying the shower tray with concrete slabs. It combines a full Marmox floor covering and a shower tray with a hob construction.

Centre or Offset Shower Tray




Cement based tile adhesive


Channel Shower Tray



Shower Tray Installation (Hobless Construction)




NOTE: The solid base shower tray only needs to be supported along all four edges and around the drain cutout. Otherwise the following installation and waterproofing steps (1) to (4) still apply.




1 Check the timber floor for flatness and level.


2 Dry position the underlay and mark the location of the drain, and the outside edge(s) of the underlay. Cut the floorboard in the pipe location and finish plumbing connections.




- 3** Fix 40 x 40mm aluminum angle to the outside(s) line of the underlay to be used as a water stop using polyurethane adhesive.




- 4** Use a polyurethane adhesive (non-solvent based), to give down the underlay to the floor. Place the underlay in position, apply downward pressure on the underlay and check for level.




- 5** Apply a bead of polyurethane on the stainless steel plate, plumber glue to the drain pipe, and fix the drainage flange in position, then apply a bead of polyurethane to the outside of the flange.



- 6** After the shower tray system is in place install the wall sheeting



- 7** Apply an approved water proof membrane to the entire surface of the underlay, flange, water stop, and the wall sheathing according to the manufacturer recommendations.



- 8** After the waterproof dries the shower can be tiled in the regular manner.